

### INSTRUCTION MANUAL

## SAFETY INFORMATION

### PLEASE READ THE FOLLOWING SAFETY INFORMATION BEFORE USE.

- Dispose of the used battery properly according to local laws and regulations regarding hazardous waste. Improper disposal could cause serious injury from fire or explosion.
- This product is intended for use with a 18650, 3.7V, 2000mAh Li-on rechargeable battery.
- Place the light in a clean and well-lit area for optimal performance.
- Ensure the light is securely mounted to the wall to prevent injuries.
- For outdoor use only.
- Inspect the product for any visible damage or defects before use. Do not use the product if it appears damaged.

### MAINTENANCE:

Regular and consistent use of the device helps extend the battery's lifespan. Remove the battery if the product will not be used for an extended period. Ensure the battery is positioned with the correct polarity when replacing it.


### CLEANING:

Clean the surface of the fixture with a soft, dry, or slightly damp cloth. Never use a cleaner with chemicals, solvents, or harsh abrasives to clean the product.


### STORAGE:

It is recommended to store the light indoors during the winter months, as the batteries are not designed to withstand freezing temperatures or frost.


## PARTS INCLUDED



A: 2 x Wall Lights



B: 4 x Wall Anchors




C: 4 x Screws

## HOW TO INSTALL THE LIGHT

### Location selection

Choose a location where the light receives direct sunlight for at least 8 hours each day.

Shaded areas will affect the battery's charging performance. Avoid placing the light in the shadow of buildings, walls, trees, shrubs, or other objects. Do not install the light near other light sources, as this may cause the wall light to malfunction.



### Installation

1. Along a level line on the wall, mark two points corresponding to the spacing of the wall-mount holes. Drill, insert anchors B, and install screws C, leaving them about 0.1 inch proud of the wall. (Figure 1)
2. Turn the switch on wall light A to "ON," then hang the light onto the two screws C via its wall-mount holes. (Figure 2)




Figure 1




Figure 2

For first-time use, it is recommended to charge for a full day with the switch turned off.

When the switch is set to ON, the light does not turn on during the day while it charges; it turns on automatically at night. When no motion is detected, it stays at a low brightness level (15 lm). When motion is detected, it switches to high brightness (500 lm), and then reverts to low brightness after about 20 seconds.

**INSTRUCTION MANUAL****TROUBLE SHOOTING**

| Problem                                                         | Possible Cause                                                                          | Solution                                                                             |
|-----------------------------------------------------------------|-----------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| The light does not light up                                     | The light is turned off.                                                                | Press the power button to turn the light on                                          |
| The light does not light up at night or stays on during daytime | Dirty or obstructed solar panel                                                         | Clean the solar panel                                                                |
|                                                                 | The solar panel is obstructed or affected by other light sources, such as a streetlight | Relocate the light to an open area where the solar panel can receive direct sunlight |
|                                                                 | The battery cannot be recharged                                                         | Wipe the battery contact with dry cloth or replace the battery                       |

**WARNING**

**Warning:** As this wall light contains a battery, do not dispose of the light or battery in fire, as this may cause explosion or battery leakage. To avoid personal injury or death, do not open-circuit or short-circuit the battery. To protect the environment, please recycle the battery or dispose of it at designated locations in accordance with local regulations.

**LIMITED WARRANTY****DO NOT RETURN THIS PRODUCT TO THE STORE**

This product comes with a 1-year warranty starting from the date of purchase. If you have questions or need assistance, please call customer service at 1-888-445-8974 or email us at: [support@solarlights.westinghouse.com](mailto:support@solarlights.westinghouse.com)

**Warranty Notice:**

To ensure full warranty coverage, this product must be purchased from an authorized retailer. Purchases made through unauthorized third-party sellers will void all warranty protections. This includes eligibility for product replacements, repairs, or customer support. Please retain your proof of purchase from an authorized source.

 and Westinghouse are trademarks of Westinghouse Electric Corporation. Used under license by Rayman Lights, Inc. All Rights Reserved.