




WSNOW20D REPLACEMENT PARTS LIST



Index Number	Description	Part Number
1	Auger	WSnow20-1
2	Scraper	WSnow20-002
3	Knob assembly	WSnow20-400
4	Snow chute	WSnow20-14
5	Cord retainer	1053285001
6	Snow discharge chute screw	WSnow20-8
7	Middle handle	WSnow20-9
8	Chute adjustment handle	WSnow20-10
9	Chute adjustment rod	WSnow20-11
10	Belt	WSnow20-52