




iGen1500c

DIGITAL INVERTER GENERATOR




WESTINGHOUSE OUTDOOR POWER EQUIPMENT

777 Manor Park Drive, Columbus, OH 43228 • WestinghousePortablePower.com

If you have questions or need assistance, please call customer service at 855-944-3571.

123596 Rev01 10/22
iGen1500c Rev 02

iGen1500c
Exploded View A
Generator



iGen1500c

Parts List A (Generator)


No.	Description	Part Num.
1	Engine	100240008
2	Left Frame Assembly (Inc. Nos. 17, 25, and 42)	100280038
3	Right Frame Assembly (Inc. Nos. 6, 17, 20, 25, 35, 39, 42, and 47)	100280039
4	Left Panel Assembly (Inc. No. 43)	100150023
5	Right Panel Assembly (Inc. No. 43)	100150024
6	Spark Plug Cover	504699-126
7	Front Frame (Inc. No. 39)	100140014
8	Rear Frame w/Seal (Inc. No. 39)	100030013
9	Control Panel Assembly (Inc. Nos. 11, 12, 18, 27, 28, 29, and 39)	100110030
10	Spill Guard	504703
11	Receptacle (L5-20R)	6032
12	Dust Cover	9194
13	Fuel Tank	504707
14	Fuel Hose (103 mm)	504708
15	Fuel Hose (65 mm)	504709
16	Fuel Hose (170 mm)	504710
17	Engine Isolation Pad	504711
18	Circuit Breaker (20A)	9293-20
19	Accessory Tray (Rubber Pad)	504702
20	DC Voltage Regulator	504714
21	CO Module Assembly (Inc. No. 34)	100450007
22	Inverter Module Assembly	100100018
23	Fuel Switch Assembly (Inc. Nos. 24, 36 and 38)	100360009

No.	Description	Part Num.
24	Cable	504718
25	Bolt (M8 x 25 mm)	92351
26	Frame Isolation Rubber Pad	504745
27	Circuit Breaker (9A)	9293-9
28	ECO Switch w/Cover	9295
29	Reset Switch	9230
30	Fuel Hose Clamp	94489
31	Fuel Hose Clamp	94490
32	Fuel Filter	516401
33	Filter	500171
34	Screw (M4.2 x 16 mm)	92195
35	Screw (M4.8 x 16 mm)	92108
36	Fuel Switch Knob	504562
37	Fuel Tank Cap	504738-231
38	Screw (M4 x 16 mm)	92032
39	Screw (M5 x 12 mm)	91825
40	Fuel Tank Isolation Rubber Pad (C)	500009
41	Bolt (M6 x 12 mm)	91325
42	Lock Clip	500045
43	Clip	504237
44	Screwdriver	99506
45	Spark Plug Wrench	504726
46	Funnel	500942
47	Screw (M4 x 25 mm)	92102

iGen1500c

Exploded View B

Engine



iGen1500c

Parts List B (Engine)

No.	Description	Part Num.
1	Bolt (M6 x 16 mm)	91329
2	Start Puller Assembly w/Recoil Handle (Inc. Nos. 1)	50580019
3	Engine Shroud Assembly (Inc. Nos. 4 and 5)	50590021
4	Air Filter	2178
5	Air Filter Cover	2179
6	Bolt (M6 x 12 mm)	91325
7	Trigger	346014
8	Alternator Assembly (Inc. Nos. 1, 6, 7 and 34)	50170012
9	Blast Pipe	95614
10	Dipstick Assembly	245601-138
11	Muffler	346036
12	Nut (M6)	90016
13	Spark Arrester Assembly	6967
14	Spark Plug	97124
15	Cylinder Head Assembly (Inc. Nos. 16, 17, and 18)	50140027
16	Carburetor Connection Block	346026
17	Intake Gasket	346025
18	Exhaust Seal Washer	346042

No.	Description	Part Num.
19	Breathing Valve Cover	346040
20	Breathing Valve Gasket	346041
21	Gasket	346037
22	Cylinder Head Cover	346038
23	Bolt (M5 x 20 mm)	91389
24	Ignition Coil	346034
25	Bolt (M6 x 20 mm)	91330
26	Carburetor Washer	346027
27	Carburetor Assembly	346028
28	Intake Pipe	346030
29	Press Plate	346029
30	Nut (M5)	90015
31	Stepper Motor	345026
32	Bolt (M3 x 8 mm)	92239
33	Carburetor, Intake Pipe, and Stepper Motor Assembly (Inc. Nos. 26, 27, 28, 29, 30, 31, and 32)	50040138
34	Starter Pully	346022