



Replacement Parts List

iGen2800DFc




iGen2800DFc

WESTINGHOUSE OUTDOOR POWER EQUIPMENT

777 Manor Park Drive, Columbus, OH 43228 | WestinghousePortablePower.com
If you have questions or need assistance, please call customer service at 855-944-3571.

128071 07/25
iGen2800DFc Rev02

iGen2800DFc
Exploded View A
Generator




iGen2800DFc

Parts List A (Generator)

No.	Description	Part Num.
1	FUEL CAP	505349
2	FUEL STRAINER	504628
3	SPARK PLUG TOOL, FUNNEL, SCREW DRIVER KIT	100440009
4	INVERTER MODULE	505373
5	LEFT PANEL KIT ASSEMBLY	100150080
5.1	LEFT PANEL	504621-221H
5.2	KNOB KIT ASSEMBLY	100340007
6	MUFFLER PANEL	100030017
7	RIGHT FRAME KIT ASSEMBLY	100280144
7.1	RIGHT PANEL	504539-221
7.2	KNOB KIT ASSEMBLY	100340007
8	CONNECTOR	505473
9	CONTROL PANEL BACK COVER	100140033

No.	Description	Part Num.
10	PANEL ASSEMBLY	505482
11	OBSERVATION COVER	504542-126
12	DC VOLTAGE REGULATOR	505467
13	OIL BOTTLE	99628
14	FUEL SWITCH KIT ASSEMBLY	100360046
15	FUEL FILTER	516401
16	CO MODULE	599098
17	SECONDARY PRESSURE REDUCING KIT	100440017
17.1	SECONDARY PRESSURE REDUCING VALVE	50280085VN
18	CABLE	504809
19	GASOLINE SENSOR ASSEMBLY	100530001
20	WRENCH	99585

iGen2800DFc
Exploded View B
Control Panel




iGen2800DFc
Parts List B (Control Panel)

No.	Description	Part Num.
1	L5-20R RECEPTACLE	6032
2	L5-20R DUST COVER	9194
3	GROUNDING BOLT	9074
4	TT-30R RECEPTACIE	6015
5	TT-30R DUST COVER	6849
6	20A THERMAL PROTECTOR	9414-20
7	30A THERMAL PROTECTOR	9414-30
8	POWER INDICATOR LIGHT	9406

No.	Description	Part Num.
9	VOLTAGE RESET SWITCH	9230
10	ROCKER SWITCH ASSEMBLY	9421
11	LED	9480
12	ECO SWITCH ASSEMBLY	9421
13	PARALLEL SOCKET ASSEMBLY	9411
14	CO SHUTOFF EVENT INDICATOR	9322
15	SYSTEM FAULT EVENT INDICATOR	9326

iGen2800DFc
Exploded View C
Engine



iGen2800DFc

Parts List C (Engine)

No.	Description	Part Num.
1	DIPSTICK	50350015
2	OIL SENSOR	345020
3	CYLINDER HEAD KIT ASSEMBLY	50020183
3.1	CYLINDER HEAD COVER KIT ASSEMBLY	50010092
3.1.1	BTEATHING BOARD GASKET	201104
3.1.2	CYLINDER COVER BREATH BOARD	201103
3.2	CYLINDER HEAD COVER GASKET	96006
3.3	CARBURETOR PAPER PAD	96121
3.4	CARBURATOR THERMAL INSULATION	345010
3.5	CONNECTING BLOCK GASKET	96007
3.6	CYLINDER HEAD GASKET	96387
3.7	EXHAUST GASKET	345029
3.8	HANDLE CONNECTOR	200183

No.	Description	Part Num.
4	SPARK PLUG	97130
5	EXHAUST MUFFLER KIT ASSEMBLY	50240061
5.1	SPARK ARRESTER	6967
6	IGNITION COIL	345073
7	CARBURETOR KIT ASSEMBLY	50040279
7.1	STEPPER MOTOR	330089
8	BLOWER HOUSING KIT ASSEMBLY	50590043
8.1	AIR FILTER	2410
8.2	AIR FILTER TOP COVER	2411
9	START PULLER ASSEMBLY	50580055
10	IGNITION TRIGGER	345022
11	MOTOR STATOR CUP ASSEMBLY	50180043
12	SCRAPER RING SET ,PISTON	211603