




Replacement Parts List

WGen14500DF





WGen14500DF

WESTINGHOUSE OUTDOOR POWER EQUIPMENT

777 Manor Park Drive, Columbus, OH 43228 | WestinghousePortablePower.com
If you have questions or need assistance, please call customer service at 855-944-3571.

123913 Rev01 09/24
WGen14500DF Rev01

WGen14500DF
Exploded View A
Generator




WGen14500DF

Parts List A (Generator)

No.	Description	Part Num.
1	KNOB	552034
2	ALTERNATOR KIT ASSEMBLY	60140092
2.1	CARBON BRUSH	6186
2.2	ALTERNATOR END COVER	533304-221
3	WHEEL KIT ASSEMBLY	60060054
3.1	AXLE	501137
3.2	FLAT WASHER	94213
3.3	WHEEL	523623
3.4	COTTER PIN	548301
4	EXHAUST MUFFLER KIT ASSEMBLY	60030059
4.1	SPARK ARRESTER	6859
5	FUEL TANK KIT ASSEMBLY	60010186
5.1	FUEL TANK CAP ASSEMBLE	60510007
5.2	FUEL TANK FILTER	518801
5.3	FUEL GAUGE	6668
5.4	FUEL NOZZLE	503782
6	FOOT BRACKET KIT ASSEMBLY	60150068
7	BATTERY	511092

No.	Description	Part Num.
8	HANDLE ASSEMBLY	60540009
9	FUNNEL, WRENCH, SPARK PLUG TOOL	60440043
10	AUTOMATIC VOLTAGE	534905
11	PANEL KIT ASSEMBLY	60040134
11.1	BOLT M6*12	91327
12	BATTERY HOLDER ASSEMBLY	60200054
13	BATTERY CABLE ASSEMBLY	60200055
14	FUEL LINE CLAMP	94411
15	FUEL LINE	96930
16	FUEL LINE CLAMP	94412
17	FUEL LINE	96983
18	FUEL LINE CLAMP	94402
19	FUEL SWITCH	501221
20	PRESSURE REDUCING VALVE KIT ASSEMBLY	60490021
21	CHARGER	511076
22	REMOTE KEY	1349
23	OIL BOTTLE	99576
24	HIGH PRESSURE HOSE	517324

WGen14500DF
Exploded View B
Control Panel




WGen14500DF

Parts List B (Control Panel)

No.	Description	Part Num.
1	LOW IDLE SWITCH	6685
2	BATTERY CHARGING PORT 2.5MM	6387
3	ONE PUSH BOTTON SWITCH	536002
4	POWER INDICATOR	6393
5	BATTERY SWITCH	6502
6	EFFICIENCY MODE SWITCH	9032
7	ST SWITCH PORT	6488
8	CIRCUIT BREAKER 30A/CSA/1.25 RED	6436-30
9	DOUBLE USB DC SOCKET	1149
10	30A THERMAL PROTECTOR	6439-30
11	DATA CENTER/TIME ACCUMULATOR	6041
12	50AMP FLIP CIRCUIT BREAKER	6513-50
13	20A THERMAL PROTECTOR	6439-20

No.	Description	Part Num.
14	R5-20 GFCI	6275
15	DUPLEX RS-20A GFCI OUTLET WATERPROOF CAP	6845
16	GROUND BOLT ASSEMBLY	6386
17	L5-30R RECEPTACLE	6383
18	L5-30R WATERPROOF CAP	6847
19	L14-30R RECEPTACLE	6385
20	L14-30R WATERPROOF CAP	6848
21	L14-50R RECEPTACLE	6254
22	L14-50R WATERPROOF CAP	6850
23	WR0711 CONTROL MODULE	6697
24	EC16 CHARGING MODULE	6397
25	RECTIFIER	6666
26	ENERGY-SAVING CONTROL MODULE	549407

WGen14500DF
Exploded View C
Engine



WGen14500DF

Parts List C (Engine)

No.	Description	Part Num.
1	RIGHT IGNITION COIL	50100029
1.1	METAL SHIELDING CAP	2106
2	LEFT IGNITION COIL	50100028
2.2	METAL SHIELDING CAP	2106
3	HEAT SINK KIT ASSEMBLY	50710001
4	STARTER MOTOR KIT ASSEMBLY	50260011
4.1	STARTING SOLENOID	5982
5	CARBURETOR KIT ASSEMBLY	50040239
5.1	CARBURETOR OVERFLOW PIPE	95464
5.2	AIR FILTER CONNECTING PIPE	95905
5.3	CARBURETOR HEAT SHIELD	96141
5.4	CARBURETOR GASKET	96137
5.5	STEPPER MOTOR	329929
5.6	STEPPER MOTOR	329924
5.7	AIR FILTER CONNECTING PIPE GASKET	96138
6	RECOIL STARTER KIT ASSEMBLY	50090129
7	AIR FILTER KIT ASSEMBLY	50030113
7.1	AIR FILTER	5061
7.2	AIR FILTER TOP COVER	2351
8	CYLINDER HEAD KIT ASSEMBLY	50020165
8.1	GASKET	96135
8.2	LEFT CYLINDER HEAD COVER	321100
8.3	CYLINDER HEAD COVER GASKET	96136
8.4	TEMPERATURE SENSOR	325801

No.	Description	Part Num.
8.5	OIL PLUG	321400
9	CYLINDER HEAD KIT ASSEMBLY	50020166
9.1	GASKET	96135
9.2	RIGHT CYLINDER HEAD COVER	321101
9.3	CYLINDER HEAD COVER GASKET	96136
10	DIPSTICK ASSEMBLY	325600
11	OIL DRAIN BOLT ASSEMBLY	50550009
11.1	FLAT WASHER	94242
12	FUEL PUMP KIT ASSEMBLY	50690012
12.1	FUEL PUMP	329914
12.2	FUEL FILTER	516401
13	OIL DRAIN SOLENOID ASSEMBLY	50550016
14	OIL FILTER	329908
15	SPARK PLUG	97110
16	OIL PROTECTOR	325101
17	DUAL CHAMBER INTAKE PIPE	95907
18	INTAKE PIPE GASKET	96139
19	OIL SENSOR	325100
20	CHARGING COIL	97212
21	EXHAUST GASKET	96140
22	BREATHING VALVE GASKET	96133
23	IMPELLER	324600
24	OIL FILTER	329906