




Replacement Parts List

WGen20000TFc




WGen20000TFc

WESTINGHOUSE OUTDOOR POWER EQUIPMENT

777 Manor Park Drive, Columbus, OH 43228 | WestinghousePortablePower.com
If you have questions or need assistance, please call customer service at 855-944-3571.

128015 11/24
WGen20000TFc Rev01

WGen2000TFc Exploded View A Generator




WGen20000TFc

Parts List A (Generator)

No.	Description	Part Num.
1	CO MODULE KIT ASSEMBLY	60450023
2	ALTERNATOR KIT ASSEMBLY	60140105
2.1	ALTERNATOR END COVER ASSEMBLY	60100012
2.2	CARBON BRUSH ASSEMBLY	501183
3	WHEEL KIT ASSEMBLY	60060052
3.1	WHEEL	523694
3.2	COTTER PIN	548301
3.3	AXLE	501180
4	EXHAUST MUFFLER KIT ASSEMBLY	60030066
4.1	SPARK ARRESTER	6859
5	FUEL TANK KIT ASSEMBLY	60010189
5.1	FUEL TANK CAP ASSEMBLE	60510011
5.1.1	FUEL CAP	519429
5.2	FUEL GAUGE	6706
5.3	FUEL TANK FILTER	518801
5.4	FUEL NOZZLE	503782
5.5	ONE WAY VALVE ASSEMBLY	546609
5.6	FUEL TANK	700909-116
6	FOOT BRACKET KIT ASSEMBLY	60150074
7	BATTERY	511093
8	HANDLE KIT ASSEMBLY	60180046

No.	Description	Part Num.
9	FUNNEL, WRENCH, SPARK PLUG WRENCH	60440039
10	AUTOMATIC VOLTAGE REGULATOR ASSEMBLY	60110029
11	PANEL KIT ASSEMBLY	60040130
11.1	BOLT M6X12	91327
12	BATTERY HOLDER ASSEMBLY	60200043
13	BATTERY CABLE ASSEMBLY	60020044
14	GASOLINE PUMP OUTLET PIPE	96790
15	FUEL LINE	96753
16	FUEL FILTER	516401
17	E-Start Controller ASSEMBLY	60680001
18	HIGH PRESSURE PIPE	958002
19	OIL BOTTLE ASSEMBLY	99655
20	KEY SET	1349
21	CHARGER	552038
22	CLEAR FUEL FILTER	516602
23	TRANSFER SWITCH ASSEMBLY	60550029
23.1	KNOB KIT ASSEMBLY	60660003
23.2	FUEL LINE	96771
23.3	LOW PRESSURE HOSE ASSEMBLY	60020009
24	PRESSURE REDUCING VALVE KIT ASSEMBLY	60490031

WGen20000TFc
Exploded View B
Control Panel




WGen20000TFc
Parts List B (Control Panel)

No.	Description	Part Num.
1	L14-50R (120/240-V, 50A OUTLET)	6254
2	PLASTIC COVER L14-50R	6414
3	50AMP FLIP CIRCUIT BREAKER	6513-50
4	DATA CENTER	6041
5	LOW IDLE SWITCH	6685
6	L5-30R RECEPTACLE	6383
7	PLASTIC COVER L14-30R	6413
8	83AMP FLIP CIRCUIT BREAKER	6513-83
9	30A THERMAL PROTECTOR	6441-30

No.	Description	Part Num.
10	OUTLET-DUPLEX RS-20A GFCI	6275
11	PLASTIC COVER 20A GFCI	6412
12	20A THERMAL PROTECTOR	6441-20
13	GROUND BOLT ASSEMBLY	6386
14	RED CIRCUIT BREAKER 30A/CSA/1.25	6436-30
15	L14-30 RECEPTACLE	6385
16	PLASTIC COVER L14-30	6413
17	ELECTRONIC SPEED CONTROLLER	549406

WGen20000TFc
Exploded View C
E-Start Controller




WGen20000TFc
Parts List C (E-Start Controller)

No.	Description	Part Num.
1	CO INDICATOR ASSEMBLY	1412
2	POWER INDICATOR	6393
3	POWER SWITCH	6502
4	CHARGING SOCKET 2.0mm	6387

No.	Description	Part Num.
5	ONE PUSH BOTTON SWITCH	536002
6	AVIATION SOCKET GXP20-7P	6488
7	WR0720_1C MODULE	1320

WGen20000TFc
Exploded View D
Engine



WGen20000TFc

Parts List D (Engine)

No.	Description	Part Num.
1	LEFT IGNITER KIT ASSEMBLY	50100066
1.1	METAL SHIELDING CAP	2295
2	RIGHT IGNITER KIT ASSEMBLY	50100067
2.1	METAL SHIELDING CAP	2295
3	OIL CONDENSER ASSEMBLY	50820002
3.1	OIL CONDENSER	388501
4	VENTILATION HOOD INLET NET ASSEMBLY	50840001
5	STARTER MOTOR KIT ASSEMBLY	50260010
5.1	STARTING SOLENOID	2303
6	CARBURETOR KIT ASSEMBLY	50040246
6.1	CARBON CANISTER AND FUEL TANK CONNECTING PIPE	95127
6.2	AIR FILTER CONNECTING PIPE	95966
6.3	CARBURETOR CONNECTION BLOCK	382301
6.4	STEPPER MOTOR	329929
6.5	STEPPER MOTOR	329924
6.6	GASKET	96207
6.7	GASKET	96208
7	AIR FILTER KIT ASSEMBLY	50030117
7.1	AIR FILTER	2296
7.2	AIR FILTER TOP COVER	2297
7.3	AIR FILTER SIDE COVER	2298
8	RIGHT FYLINDER HEAD ASSEMBLY	50020143
8.1	INTAKE WASHER	96359
8.2	CYLINDER HEAD COVER	381101

No.	Description	Part Num.
8.3	CYLINDER HEAD COVER GASKET	96205
8.4	OIL PLUG	381401
9	LEFT FYLINDER HEAD ASSEMBLY	50020144
9.1	INTAKE WASHER	96359
9.2	CYLINDER HEAD COVER	381102
9.3	CYLINDER HEAD COVER GASKET	96206
9.4	OIL PLUG	381401
10	SPEED GOVERNOR KIT ASSEMBLY	50060044
11	DIPSTICK	385602
12	OIL DRAIN BOLT WASHER ASSEMBLY	50550009
12.1	OIL DRAIN PLUG WASHER	94242
13	EXHAUST PIPE	95643
14	INTAKE WASHER	96202
15	CHARGING MODULE	388302
16	FUEL PUMP KIT ASSEMBLY	50690013
16.1	FUEL PUMP	329914
17	OIL DRAIN SOLENOID ASSEMBLY	50550010
18	OIL FILTER	389904
19	TEMPERATURE SENSOR	325801
20	SPARK PLUG 21MM	97110
21	EXHAUST GASKET	96209
22	EXHAUST PIPE	95934
23	LOW PRESSURE HOSE ASSEMBLY	50300042