




Replacement Parts List

WGen5300DFcv




WGen5300DFcv

WESTINGHOUSE OUTDOOR POWER EQUIPMENT

777 Manor Park Drive, Columbus, OH 43228 | WestinghousePortablePower.com
If you have questions or need assistance, please call customer service at 855-944-3571.

xxxxxx 07/25
WGen5300DFcv Rev01

**WGen5300DFcv
Exploded View A
Generator**




WGen5300DFcv

Parts List A (Generator)

No.	Description	Part Num.
1	EXHAUST MUFFLER KIT ASSEMBLY	60030046
1.1	SPARK ARRESTER	6967
2	PRESSURE REDUCING VALVE KIT ASSEMBLY	60490042
3	OIL BOTTLE ASSEMBLY	99635
4	PANEL KIT ASSEMBLY	60040148
5	CO MODULE	599104
6	ALTERNATOR KIT ASSEMBLY	60140116
6.1	CARBON BRUSH	599019
6.2	AUTOMATIC VOLTAGE REGULATOR ASSEMBLY	60110035
6.3	ALTERNATOR END COVER ASSEMBLY	60100013
7	FOOT BRACKET KIT ASSEMBLY	60150076
8	FUNNEL, SPARK PLUG TOOL, WRENCH	60440041

No.	Description	Part Num.
9	PRESSURE REDUCING VALVE	545331
10	FUEL TANK KIT ASSEMBLY	60010216
10.1	FUEL TANK CAP ASSEMBLE	60510019
10.2	FUEL GAUGE	6517
10.3	FUEL TANK FILTER	518801
10.4	FUEL PETCOCK	518620
11	WHEEL KIT ASSEMBLY	60060063
11.1	FLAT WASHER	94224
11.2	WHEEL	523693
11.3	AXLE	524320
11.4	COTTER PIN	548301

WGen5300DFcv
Exploded View B
Control Panel




WGen3600v
Parts List B (Control Panel)

No.	Description	Part Num.
1	IGNITION SWITCH	6501
2	TIME ACCUMULATOR	6041
3	BREAKER	6434-22
4	CO INDICATOR	1042
5	VOLTAGE SELECTION SWITCH	6508
6	CO INDICATOR	1041
7	L14-30R RECEPTACLE	6385
8	L14-30R DUST COVER	6848
9	GROUND TERMINAL ASSEMBLY	6386

No.	Description	Part Num.
10	TT-30R RECEPTACIE	6015
11	TT-30R DUST COVER	6849
12	30A THERMAL PROTECTOR	6441-30
13	20A THERMAL PROTECTOR	6441-20
14	L5-20R RECEPTACLE	6032
15	L5-20R DUST COVER	6846
16	FUEL SELECTOR KNOB	599035
17	SCREW M6*12	92083
18	DUAL FUEL SELECTOR SWITCH	60550001

WGen5300DFcv Exploded View C Engine



WGen5300DFcv

Parts List C (Engine)

No.	Description	Part Num.
1	AIR FILTER KIT ASSEMBLY	50030109
1.1	AIR FILTER	5941
1.2	AIR FILTER TOP COVER	2015
2	CARBURETOR KIT ASSEMBLY	50040282
2.1	GASKET	96224
2.2	STEEL WASHER	94324
3	CYLINDER HEAD KIT ASSEMBLY	50020196
3.1	CYLINDER HEAD GASKET	96223
3.2	CARBURETOR CONNECTION BLOCK	402301
3.3	CYLINDER HEAD COVER GASKET	96225
3.4	CYLINDER HEAD INTERNAL COVER GASKET	96226
3.5	CYLINDER HEAD INTERNAL COVER	401102

No.	Description	Part Num.
3.6	INTAKE GASKET	96235
4	SPEED CONTROL BRACKET KIT ASSEMBLY	50060027
5	IGNITER KIT ASSEMBLY	50340024
6	DIPSTICK	245601-295
7	OIL DRAIN BOLT ASSEMBLY	50550014
8	MOTOR STATOR CUP ASSEMBLY	50180037
9	START PULLER KIT ASSEMBLY	50580049
10	SPARK PLUG	97108
11	OIL SENSOR	245106
12	OIL PROTECTOR	245104
13	IMPELLER	404601