




Replacement Parts List

WGen9500




WGen9500

WESTINGHOUSE OUTDOOR POWER EQUIPMENT

777 Manor Park Drive, Columbus, OH 43228 | WestinghousePortablePower.com
If you have questions or need assistance, please call customer service at 855-944-3571.

123885 Rev03 08/29
WGen9500 Rev 02

WGen9500
Exploded View A
Generator




WGen9500

Parts List A (Generator)

No.	Description	Part Num.
1	FUEL LINE CLAMP	94402
2	EXHAUST MUFFLER KIT ASSEMBLY	60030058
2.1	SPARK ARRESTER	6947
3	FOOT BRACKET KIT ASSEMBLY	60150086
4	OIL BOTTLE ASSEMBLY	99631
5	FUEL SWITCH	518202
6	REMOTE KEY	1349
7	BATTERY CABLE ASSEMBLY	60200052
8	BATTERY	511091
9	BATTERY HOLDER ASSEMBLY	60020046
10	WHEEL KIT ASSEMBLY	60060030
10.1	FLAT WASHER	94207
10.2	WHEEL	523646
10.3	AXLE	524619
10.4	COTTER PIN	548302
11	BREATHER HOSE	95014
12	PANEL KIT ASSEMBLY	60040131
13	ALTERNATOR KIT ASSEMBLY	60140103
13.1	CARBON BRUSH	599019
13.2	AUTOMATIC VOLTAGE REGULATOR ASSEMBLY	60110030
13.3	ALTERNATOR END COVER ASSEMBLY	60100013
14	CHARGER	511076

No.	Description	Part Num.
15	FUEL TANK KIT ASSEMBLY	60010181
15.1	FUEL GAUGE	6517
15.2	FUEL TANK FILTER	518801
15.3	FUEL TANK CAP ASSEMBLE	60510004
16	HANDLE WELDING KIT ASSEMBLY	60180051
17	ACCESSORY ASSEMBLY	60440040

WGen9500
Exploded View B
Control Panel



WGen9500
Parts List B (Control Panel)


No.	Description	Part Num.
1	ONE PUSH BOTTON SWITCH	536002
2	INDICATOR LIGHT	6393
3	ENGINE SWITCH	6502
4	SMART SWITCH READY	6488
5	DOUBLE USB DC SOCKET	1149
6	CHARGING SOCKET	6387
7	BREAKER	6434-38
8	TIME ACCUMULATOR	6041
9	GROUND TERMINAL ASSEMBLY	6386
10	L14-50R RECEPTACLE	6254

No.	Description	Part Num.
11	WATERPROOF CAP	6850
12	L14-30R RECEPTACLE	6385
13	WATERPROOF CAP	6848
14	THERMAL PROTECTOR	6439-30
15	THERMAL PROTECTOR	6439-20
16	GFCI OUTLET	6275
17	DUST COVER	6845
18	WR0504-1-DJMODULE	6399
19	EC08 CHARGING MODULE	6257

WGen9500

Exploded View C

Engine



WGen9500

Parts List C (Engine)

No.	Description	Part Num.
1	AIR FILTER KIT ASSEMBLY	50030108
1.1	AIR FILTER	5692
1.2	AIR FILTER TOP COVER	2301-052
2	CARBURETOR KIT ASSEMBLY	50040230
2.1	AIR FILTER GASKET	96086
2.2	CARBURETOR GASKET	96081
2.3	STEPPER MOTOR	249904
2.4	FUEL HOSE ASSEMBLY	50300045
3	CYLINDER HEAD KIT ASSEMBLY	50020151
3.1	CYLINDER HEAD GASKET	96093
3.2	CYLINDER HEAD COVER	261104
3.3	EXHAUST PIPE	95686
3.4	CYLINDER HEAD COVER GASKET	96075
3.5	CARBURETOR CONNECTION BLOCK	262301
4	SPEED GOVERNOR KIT ASSEMBLY	50060025
5	IGNITER KIT ASSEMBLY	50100025
5.1	METAL SHIELDING CAP	2105
6	DIPSTICK ASSEMBLY	260020-295
7	OIL DRAIN BOLT WASHER ASSEMBLY	50550011
7.1	OIL DRAIN BOLT WASHER	94004
8	STARTER MOTOR KIT ASSEMBLY	50260008
8.1	RELAY	6365
9	MOTOR STATOR CUP ASSEMBLY	50180036
10	START PULLER KIT ASSEMBLY	50580040
11	SPARK PLUG	97108
12	OIL SENSOR	265102
13	OIL PROTECTOR	245104
14	IMPELLER	264601