




Replacement Parts List

iGen5000




iGen5000

WESTINGHOUSE OUTDOOR POWER EQUIPMENT

777 Manor Park Drive, Columbus, OH 43228 | WestinghousePortablePower.com
If you have questions or need assistance, please call customer service at 855-944-3571.

123822 Rev02 11/24
iGen5000

iGen5000
Exploded View A
Generator




iGen5000

Parts List A (Generator)

No.	Description	Part Num.
1	GASOLINE SENSOR ASSEMBLY	100530002
2	FUEL TANK FILTER	518801
3	FUEL TANK CAP ASSEMBLE	100560002
4	REPLACEMENT PARTS ASSEMBLY	100440012
5	INVERTER MODULE	503147
6	CHARGER	511043
7	LEFT PANEL KIT ASSEMBLY	100150065
7.1	LEFT PANEL	503039-221A
8	MUFFLER PANEL KIT ASSEMBLY	100030002
8.1	COVER	503040
9	RIGHT FRAME KIT ASSEMBLY	100280123
9.1	OBSERVATION COVER	503022-221
10	RUBBER FOOT	503026
11	FRONT PANEL COVER KIT ASSEMBLY	100140030
12	WHEEL KIT ASSEMBLY	100160013
12.1	WHEEL AXLE CLIP	500321

No.	Description	Part Num.
12.2	AXEL COVER	503032
13	CONTROL MODULE	506735
14	FUEL FILTER	516401
15	PANEL KIT ASSEMBLY	100110079
15.1	PANEL ASSEMBLY	503061
16	FUEL SWITCH	503062
17	BASE OIL COVER	503052
18	DC VOLTAGE REGULATOR	503048
19	BATTERY CABLE	503165
20	BATTERY CLAMP	599606
21	HANDLE KIT ASSEMBLY	100310007
22	REMOTE KEY	506694
23	BATTERY	511089
24	OIL BOTTLE	99629
25	KNOB KIT ASSEMBLY	100340004

iGen5000
Exploded View B
Control Panel




iGen5000

Parts List B (Control Panel)

No.	Description	Part Num.
1	ENGINE SHUT OFF SWITCH	9222
2	ONE PUSH BOTTON SWITCH	9223
3	ECO SWITCH ASSEMBLY	9421
4	31A THERMAL PROTRCTOR	9414-31
5	CHARGING SOCKET	9226
6	30A THERMAL PROTRCTOR	9414-30
7	START INDICATOR	9225
8	20A THERMAL PROTECTOR	9414-20
9	INDICATOR LIGHTS (TCI)	9228
10	DUAL USB PORT	9141

No.	Description	Part Num.
11	USB DUST COVER	9299
12	OVERLOAD RESET SWITCH	9230
13	DATA CENTER	9110
14	PARALLEL SOCKET ASSEMBLY	9411
15	L5-20R RECEPTACLE	6032
16	L5-20R DUST COVER	9194
17	TT-30R RECEPTACIE	6015
18	TT-30R DUST COVER	6849
19	GROUNDING BOLT	9132

iGen5000
Exploded View C
Engine



iGen5000

Parts List C (Engine)

No.	Description	Part Num.
1	OIL DRAIN SOLENOID assembly	50550012
2	DIPSTICK ASSEMBLY	245601-295
3	CYLINDER HEAD KIT ASSEMBLY	50020169
3.1	CYLINDER HEAD GASKET	96058
3.2	EXHAUST SEAL WASHER	96055
3.3	INTAKE GASKET	96182
3.4	CARBURETOR CONNECTION BLOCK	332301
3.5	CYLINDER HEAD COVER GASKET	96200
3.6	CYLINDER HEAD COVER KIT ASSEMBLY	50010073
4	SPARK PLUG	97109
5	EXHAUST MUFFLER KIT ASSEMBLY	50240039
5.1	SPARK ARRESTER	6790
5.2	HEAT SHIELD MUFFLER	500057
6	IGNITION COIL	339909
7	AIR FILTER KIT ASSEMBLY	50030115
7.1	AIR FILTER ELEMENT	5691
7.2	AIR FILTER TOP COVER	2314

No.	Description	Part Num.
8	CARBURETOR KIT ASSEMBLY	50040242
8.1	STEPPER MOTOR ASSEMBLY	50850001
8.1.1	STEPPER MOTOR 8V DC	249949
8.1.2	STEPPER MOTOR 12V DC	249950
8.2	STEEL WASHER	94226
9	CARBURETOR AIR CLEANER KIT	50630009
9.1	FOAM FILTER	5697
9.2	CARBURETOR AIR CLEANER TOP COVER	2315
10	START PULLER KIT ASSEMBLY	50580037
11	STATOR CUP ASSEMBLY	50180038
12	OIL SENSOR	245113
13	STARTER MOTOR KIT ASSEMBLY	50260021
13.1	STARTER SOLENOID	2132
14	TEMPERATURE SENSOR	335803
15	IGNITION TRIGGER	339902
16	FAN, FLYWHEEL	334601