




Replacement Parts List

iGen5000cv




iGen5000cv

WESTINGHOUSE OUTDOOR POWER EQUIPMENT

777 Manor Park Drive, Columbus, OH 43228 | WestinghousePortablePower.com
If you have questions or need assistance, please call customer service at 855-944-3571.

123841 Rev02 12/24
iGen5000cv

iGen5000cv Exploded View A Generator




iGen5000cv

Parts List A (Generator)

No.	Description	Part Num.
1	GASOLINE SENSOR ASSEMBLY	100530002
2	FUEL TANK FILTER	518801
3	FUEL TANK CAP ASSEMBLE	100560002
4	REPLACEMENT PARTS ASSEMBLY	100440012
5	INVERTER MODULE	503147
6	CO MODULE	599070
7	LEFT PANEL KIT ASSEMBLY	100150073
7.1	LEFT PANEL	503039-221D
8	MUFFLER PANEL KIT ASSEMBLY	100030033
8.1	COVER	503040
9	RIGHT FRAME KIT ASSEMBLY	100280126
9.1	OBSERVATION COVER	503022-221
10	RUBBER FOOT	503026

No.	Description	Part Num.
11	PANEL REAR COVER KIT ASSEMBLY	100140030
12	WHEELS ASSEMBLY	100160013
12.1	WHEEL AXLE CLIP	500321
12.2	AXEL COVER	503032
13	OIL BOTTLE ASSEMBLY	99629
14	FUEL FILTER	516401
15	PANEL ASSEMBLY	506720
16	FUEL SWITCH	503062
17	BASE OIL COVER	503052
18	DC VOLTAGE REGULATOR	500700
19	HANDLE KIT ASSEMBLY	100310007
20	KNOB KIT ASSEMBLY	100340004
21	CO FLAMEOUT ACTUATOR	599071

iGen5000cv
Exploded View B
Control Panel




iGen5000cv
Parts List B(Control Panel)

No.	Description	Part Num.
1	ECO SWITCH	9421
2	OVERLOAD RESET SWITCH	9230
3	31A THERMAL PROTRCTOR	9414-31
4	30A THERMAL PROTRCTOR	9414-30
5	DUAL USB PORT	9141
6	USB DUST COVER	9299
7	20A THERMAL PROTECTOR	9414-20
8	IGNITER	9228
9	CO SHUTOFF EVENT INDICATOR	9322

No.	Description	Part Num.
10	SERVICE INDICATOR	9326
11	DATA CENTER	9110
12	PARALLEL SOCKET ASSEMBLY	9411
13	GROUNDING BOLT	9132
14	L5-20R RECEPTACLE	6032
15	L5-20R DUST COVER	9194
16	TT-30R RECEPTACIE	6015
17	TT-30R DUST COVER	6849

iGen5000cv
Exploded View C
Engine



iGen5000cv

Parts List C(Engine)

No.	Description	Part Num.
1	OIL DRAIN SOLENOID assembly	50550012
2	DIPSTICK ASSEMBLY	245601-295
3	CYLINDER HEAD KIT ASSEMBLY	50020169
3.1	CYLINDER HEAD GASKET	96058
3.2	EXHAUST SEAL WASHER	96055
3.3	INTAKE GASKET	96182
3.4	CARBURETOR CONNECTION BLOCK	332301
3.5	CYLINDER HEAD COVER GASKET	96200
3.6	CYLINDER HEAD COVER KIT ASSEMBLY	50010073
4	SPARK PLUG	97109
5	EXHAUST MUFFLER KIT ASSEMBLY	50240039
5.1	SPARK ARRESTER	6790
5.2	HEAT SHIELD MUFFLER	500057
6	IGNITION COIL	339909
7	AIR FILTER KIT ASSEMBLY	50030115

No.	Description	Part Num.
7.1	AIR FILTER ELEMENT	5691
7.2	AIR FILTER TOP COVER	2314
8	CARBURETOR KIT ASSEMBLY	50040248
8.1	STEPPER MOTOR ASSEMBLY	50850007
8.1.1	STEPPER MOTOR	249949
8.2	AIR FILTER GASKET	94229
9	RESONANT CAVITY KIT ASSEMBLY	50630011
9.1	FOAM FILTER	5697
9.2	RESONANT CAVITY TOP COVER	2315
10	START PULLER KIT ASSEMBLY	50580037
11	STATOR CUP ASSEMBLY	50180038
12	OIL SENSOR	245113
13	TRIGGER	339902
14	IMPELLER	334601